

### Indoor 7-Day Digital Timer


#### ELECTRICAL RATINGS:

**125 V ac 60 Hz, 15 A Resistive, 15 A General Use, 1000 W Tungsten, 500VA Electronic Ballast, 120 V ac 60 Hz, 8.3 A Ballast, 1/2HP.**

Before initial use, plug the timer in for at least 30 minutes to charge the internal battery. After the screen displays, the unit is ready for programming.

#### 1. Button Layout

- LCD – LCD display panel
- ON/OFF – Function on and off
- SET – To set the time and event
- /RDM – (-) Decrease time, RDM) Select random mode.
- + /AUTO – (+) Increase time, AUTO) Select auto mode.
- RESET – Reset all the function
- OUTLET – Plug the lights or devices to be controlled by the timer into one of the outlets.



#### 2. Setting the Clock

- Press the SET button to set the current year. Press "+/AUTO" or "-/RDM" button to adjust the flashing number from 2015 to 2099.
- Press the SET button again to set the month. Press button "+/AUTO" or "-/RDM" to adjust the number from 01 to 12.
- Press the SET button again to set the date. Press button "+/AUTO" or "-/RDM" to adjust the number. The maximum date will depend on which month you choose.
- Press the SET button again to set the Day Light Savings Time (DST) function. Press button "+/AUTO" or "-/RDM" to setting AUTO mode or OFF mode.

When DST setting is on AUTO:

Timer schedule will automatically move ahead 1 hour on the Sunday of the second week in March at 02:00am every year.

The timer will automatically adjust back 1 hour on the Sunday of the first week in November at 02:00am every year.

- Press the SET button again to set the hour. Press button "+/AUTO" or "-/RDM" to adjust the number from 12AM–11AM to 12PM–11PM.
- Press the SET button again to set the minutes. Press button "+/AUTO" or "-/RDM" to adjust the number from 00 to 59.
- Press the SET button again to set the Astronomic function. Press button "+/AUTO" or "-/RDM" to adjust three different areas to your current location.

1. NORTH: 2. CENTRAL: 3. SOUTH:



The map below will determine what zone the timer is being used.



Once the zone is determined the time will automatically set the sunrise and sunset time.

- Press the SET button again to adjust the Sunrise time. Press "+/AUTO" or "-/RDM" button to adjust ±2 hours, Press ON/OFF back to current Sunrise time. If AM twinkling it means that setting Sunrise time.
- Press the SET button again to adjust the Sunset time. Press "+/AUTO" or "-/RDM" button to adjust ±2 hours, Press ON/OFF back to current Sunset time. If PM twinkling it means that setting Sunset time.
- Press the SET button again to set event 1 ON.

- Press the "+/AUTO" or "-/RDM" button again to set event 1–DAY(s). Press the "+/AUTO" or "-/RDM" button repeatedly until the display shows the DAY(s) when you want then press "+/AUTO" or "-/RDM" button. The options are: All days of the week MO, TU, WE, TH, FR, SA, SU.

- Press the "+/AUTO" or "-/RDM" button again to set event 1 time ON.

Press the "+/AUTO" or "-/RDM" button to set hours. Hours setting mode:

- 12-hour clock AM/PM
- Sunrise/Sunset

- If the step 12. is set Sunrise/Sunset at the same time, press set to next OFF.

- If the step 13. is set time, press set for event 1 to ON as the display in left. Press button "+/AUTO" or "-/RDM" to adjust from 00–59.

- In 12–14. setting process, press the ON/OFF will clear event 1 on.

- In case of an operational failure, press the set button to next (1–OFF) setting as the display in left.

- Press SET button to OFF event 1 week, total 7 ON/OFF finish setting display will return to standby.

- In setting process on hold for 30 second, save setting will return to standby.

- In setting process press SET button for 3 second, save setting will return to standby.

#### 3. Setting the AUTO and RDM

- Press the +/AUTO button to AUTO mode.
- AUTO OFF — When the screen display ON, press ON/OFF button and +/AUTO button.
- AUTO ON — AUTO mode has been selected the device will be ON and will stay ON until another scheduled event takes place.
- Press the -/RDM button to RDM mode. When RDM setting is ON: Random setting will increase or decrease the time on your ON/OFF setting by 30 minutes.
- RDM OFF — When the screen display ON, press ON/OFF button and -/RDM button.
- RDM ON — RDM mode has been selected the device will be ON and will stay ON until another scheduled event takes place.

