

# MODEL TM-044 OUTDOOR DIGITAL TIMER

## ELECTRICAL RATINGS:

8.3 AMPS RESISTIVE LOAD

8.3AMPS GENERAL PURPOSE LOAD

1000 WATTS TUNGSTEN LOAD

125Vac, 60Hz

## INSTRUCTION MANUAL

1. Mount the device on wall near a G.F.C.I. outlet. The nail or screw head must extend at least 3/16" out from the wall. Hang the device on the nail or screw using the slot on the back of the device.
2. The device must be mounted in a vertical position with the receptacle facing downward and with the receptacle at least 1.4 M above the ground level.
3. Plug the power supply cord of the device into the G.F.C.I. outlet.
4. When outlet not in use rotate the safety cover clockwise to CLOSE.

## OPERATION

Press the button on the timer to select one of the following settings

SELECT	DESCRIPTION
F	No Power
O	Power Constantly on
D	On automatically at dusk and off at dawn
1 to 9	On at dusk. Set off time for 1-9 hours. *
1. to 9	On immediately. Set off time for 1-9 hours.*

\* Cycle repeat every 24 hours

## CAUTION

1. Total cumulative wattage of all lights must not exceed 1000 watts.
2. Use three-conductor outlet only.
3. Do not immerse in water



MADE IN CHINA